

SPANVALL BIG SPREADER

PRODUCT DESCRIPTION

Spanvall Big Spreader is specially designed for Spanvall bedding products for poultry farms.

The spreader is easy to adapt to a loader, tractor or telescopic handler. The adjustable harness is easy to replace with conventional screws, so it can be quickly and easily assembled with another loader or telescopic handler.


An adapter with three-point linkage is used for tractor. The spreader is hydraulically driven with a minimum output of 30 l/m oil flow

**Operates with
hydraulic drive**

**2500 m² in
20-25 minutes**

**Spread very quickly,
efficiently and conveniently**


**No manual work –
Labour and time saving**




**Easy to adapt on any loader,
tractor or telescopic handler**

HOW TO USE

- 1 Place the spreader in front/
or behind the loader



- 2 Put bedding in the spreading machine





- 3 Spread the bedding



Scan to watch
spreader in action

MEASUREMENTS



Loading capacity: **2,2 m³**

Spreading wide: **4-10 m**

Net weight: **770 kg**

Gross weight: **1030 kg**

HS code: **84368090**