

# SPANVALL MEDIUM SPREADER

## PRODUCT DESCRIPTION

Spanvall Medium Spreader is specially designed for Spanvall bedding products for poultry farms.

The spreader is easy to adapt to a bobcat  
The adjustable harness is easy to replace with conventional screws, so it can be quickly and easily assembled with another loader.


An adapter with three-point linkage is used for tractor. The spreader is hydraulically driven with a minimum output of 30 l/m oil flow

**Operates with  
hydraulic drive**

**2500 m<sup>2</sup> in  
20-25 minutes**

**Spread very quickly,  
efficiently and conveniently**


**No manual work -  
Labour and time saving**




**Easy to adapt on a bobcat**

## HOW TO USE

1 Install the spreader to the bobcat



2 Put bedding in the spreading machine





3 Spread 1 cm the bedding



Scan to watch  
spreader in action

## MEASUREMENTS



Loading capacity: **1,4 m<sup>3</sup>**

Spreading wide: **5-6 m**

Net weight: **500 kg**

Gross weight: **550 kg**

HS code: **84368090**