

A large red Spanvall Bedding Spreader is shown in a large indoor facility, likely a warehouse or showroom. The machine is mounted on a green tractor. The spreader has two large red hopper-like sections with the brand name and model printed on them. The background shows a long, well-lit industrial space with high ceilings and yellow overhead lighting.

**SPANVALL®**  
WORLD CLASS BEDDING

# SPANVALL BIG SPREADER

🌐 [www.spanvall.com](http://www.spanvall.com)

☎ + 45 70 26 01 81

# SPANVALL BIG SPREADER

## PRODUCT DESCRIPTION

Spanvall Big Spreader is specially designed for Spanvall bedding products for poultry farms.

The spreader is easy to adapt to a loader, tractor or telescopic handler. The adjustable harness is easy to replace with conventional screws, so it can be quickly and easily assembled with another loader or telescopic handler.


An adapter with three-point linkage is used for tractor. The spreader is hydraulically driven with a minimum output of 30 l/m oil flow

**Operates with  
hydraulic drive**

**2500 m<sup>2</sup> in  
20-25 minutes**

**Spread very quickly,  
efficiently and conveniently**


**No manual work –  
Labour and time saving**



**Easy to adapt on any loader,  
tractor or telescopic handler**

## HOW TO USE

- 1 Place the spreader in front/  
or behind the loader



- 2 Put bedding in the spreading machine



- 3 Spread the bedding



Scan to watch  
spreader in action



MEASUREMENT

SPANVALL®  
WORLD CLASS BEDDING

